

Errata for "Operation Guide"

Please revise the following clerical error in the Operation Guide.

P.53

(Add) If you are using Windows 7, open the printer driver's setting screen as follows.

[Start] → [Control Panel] → [Hardware and Sound] → [Devices and Printers] → [Nisca PR-C101] → [Printing preferences]

If you are using Windows 8, open the printer driver's setting screen as follows.

[Settings] → [Control Panel] → [Hardware and Sound] → [View devices and printers] → [Nisca PR-C101] → [Printing preferences]